BATTERY INFORMATION

The driver requires a 9V alkaline non-rechargeable battery. For example:



<u>Do not use non-alkaline or rechargeable</u> batteries

The battery is located behind the slide panel on the back of the driver.



- Remove the old battery & gently insert new battery
- Press & hold ON/OFF button until the light on the display screen comes on
- Wait until the picture of the syringe on the display screen disappears
- Press YES (green) to confirm syringe brand & size
- Press YES (green) to resume infusion
- Press YES (green) to confirm remaining volume, duration & rate of infusion
- Press YES (green) to start the infusion

Don't worry if you have incorrectly inserted the battery as this will not damage the driver. Just remove it & re-align it correctly.

IF YOU REQUIRE ASSISTANCE WITH YOUR SYRINGE DRIVER PLEASE CONTACT:

РН				

This information has been adapted from the Omanga & Cranford Hospice brochures



NIKI T34 SYRINGE DRIVER USE AT HOME




A syringe driver may be used to give prescribed medication when a patient is unable to take medicine by mouth, or for pain or other symptoms

The NIKI T34 syringe driver consists of a syringe containing medication which ensures delivery over a given period of time, usually 24 hours. Attached to the syringe driver is a piece of tubing with a needle, which is gently inserted under the skin & secured in place with an adhesive covering.

The visiting Nurse will explain & demonstrate all you need to know about the syringe driver & will call regularly to review your symptoms & medication.

You need to have at least 2x9 Volt Alkaline non-rechargeable batteries available at home.

NIKI T34 SYRINGE DRIVER



There are 2 indicators that show the syringe driver is working satisfactorily:

- 1. The LED light on the keypad will flash green one flash every 30 seconds
- 2. The display screen will show the infusion details



(The display shown above is an example only, the numbers on your display may be different)

ALARMS & TROUBLESHOOTING

If an alarm sounds for a short time:

- The infusion will continue
- A message appears on the display screen indicating the cause:
 - Low battery change the battery your nurse will show you how
 - Near end the infusion will end soon & a nurse will prepare the new syringe
- This message will alternate with the "infusion running" screen

If a continuous alarm sounds:

- The infusion will stop
- The LED indicator turns to red
- A message appears on the display screen indicating the cause

RESOLVING THE CAUSE OF THE ALARM

Read the message on the display of the pump & then press YES to silence the alarm:

Blockage – check the line is not kinked, unkink then press YES (green) to restart the infusion. If the alarm repeats, press STOP (red), turn OFF the driver & call your hospital or health centre

Syringe displaced – syringe not fitted correctly or displaced. The screen message shows what to check – advise the hospital or community health centre

End of Infusion – turn OFF the driver

Pump paused too long – press YES to restart

Syringe Empty – turn OFF the driver

End battery – change the battery & restart the syringe driver, see instruction overleaf.

CARE OF THE PUMP

- * It is important that pump is not dropped.

 If it is dropped, return to service provider for checking.
- * Do not use harsh chemicals to clean the pump. A slightly damp cloth is sufficient.
- * Do not use non-alkaline or rechargeable batteries
- * Do not wear pump when having an MRI



SHOWERING & BATHING

*DO NOT IMMERSE THE SYRINGE DRIVER IN WATER WHILE SHOWERING OR BATHING THE PUMP SHOULD NOT GET WET!!

Before showering or bathing:

Wrap the syringe driver in one and then a second plastic bag & tie the end of bags & ensure the bags are not in the direct flow of the water. Some people find it helpful to hang bags from a coat hanger away from water.

If the driver has been immersed in water or gets wet, stop the infusion & inform the hospital or community health centre as soon as possible